


Reusable Strain Relief and Fitting

Assembly Instructions



1. Make a square cut on the hose end. Slide strain relief or nut onto the hose.
2. Apply lubricant to fitting barb. Place fitting against a stationary surface and push hose over barb until the hose reaches the threads.
3. Slide strain relief or nut down to fitting.
4. Hold strain relief or nut secure with one wrench, and using the other wrench, turn fitting hex clockwise.