

Expansion Rings

Feature

- Used with the fire hose couplings listed on page 766

| O.D. | Length | Wall Thickness | 85/15 red brass Part # |
|--------|--------|----------------|---------------------------|
| 1" | 1-1/4" | .05 | ER10125 |
| 1-1/2" | 3/4" | .05 | ER1575 |
| | 7/8" | | ER1587 |
| | 1" | | ER1510 |
| | 1-1/4" | | ER15125 |
| 1-3/4" | 1-1/4" | .05 | ER17125 |
| 2-1/2" | 1-1/4" | .062 | ER27125 |
| | 1-1/2" | | ER27150 |
| 3" | 2" | .07 | ER3020 |




Swivel Washers

Feature

- Used on the swivel end of the fire hose couplings listed on page 766

| I.D. | O.D. | Thickness | Nitrile Rubber Part # |
|---------|---------|-----------|--------------------------|
| 1-1/16" | 1-7/16" | 1/8" | SW100F |
| 1-9/16" | 2-1/16" | | SW150 |
| 2-1/16" | 2-1/2" | | SW200 |
| 2-9/16" | 3-3/16" | 3/16" | SW250 |
| 3-1/16" | 3-3/4" | 1/4" | SW300F |
| 4-1/16" | 5-1/8" | | SW400F |
| 4-9/16" | 5-7/8" | | SW450F |
| 5-1/16" | 6-3/8" | | SW500F |
| 6-1/16" | 7-1/8" | | SW600F |



Tail Washers

Feature

- Used on the tail end of the fire hose couplings listed on page 766

| I.D. | O.D. | Thickness | Nitrile Rubber Part # |
|---------|----------|-----------|--------------------------|
| 1-1/32" | 1-5/16" | 3/16" | STW100 |
| 1-9/16" | 1-3/4" | | RTW150 |
| 1-9/16" | 1-15/16" | | STW150 |
| 1-5/8" | 2-1/8" | | DTW150 |
| 2-9/16" | 3" | 1/4" | STW250 |
| 2-5/8" | 3-1/4" | | DTW250 |
| 3-1/8" | 3-25/32" | | DTW300 |

